



Here are a few pointers to help expedite processing of your samples when they arrive at QuanTEM.

1. Choose an Asbestos, Lead or Mold QuanTEM chain of custody.
2. Legibly complete the chain of custody in its entirety. Make sure to include a phone number and email address. If you have any questions, please call and speak to one of our friendly staff members for assistance.
3. The project information provided at the top of the chain of custody and your sample ID's will appear on the final Analytical Report.
4. If the sample is an air sample, please provide the volume of air collected.
5. If the sample is a vacuum or wipe sample, please provide the area sampled.
6. Select the turnaround time you want.
7. Complete the "Report Results" area.
8. Sign the "Relinquished By", "Date & Time", and "via" sections. Include the chain of custody with the samples.
9. Label each sample with the Sample ID as it is listed on the chain of custody.
10. Bulk asbestos samples should be individually bagged and sealed to prevent contamination and potential exposure risks.